



Instructions for Amp & Boom Microphone Headset Installation

Install 2 AA batteries in the black box on the headset mic. To open the black box, pinch each side where marked and pull it open.

On the white amp, unscrew the back and install a 9-volt battery in the white amp.

Once batteries are installed, plug the pink plug from the headset into the “input” jack on the white amp. The other plug does not need to be plugged in, this is used for additional accessories (triktoys listening device or a PTT system). Ideally, you want to mount the amp behind your chest plate.

The audible static burst is best accomplished by position the mic where it is touching your lips when you talk. By having the mic at such close range, it also adds a more stormtrooper-like “raspy” voice. To do the burst, simply “spit” air into the mic or do a hard quick blow “pfft” directly into the mic at point blank range with your lips.

For a demonstration of what your static burst will sound like when done correctly, please visit http://www.triktoys.com/images/trooper_demo.wav